



RELEASED  
W/CY 05/07/11

PPP

Part Number	D350-600-142	Box Part Number	MBX115 B/T	Dimension	
Description	Spacepod, Upward Opening, RH	Other Packaging	MFSP Kit		
		Logo Decals	D3567-2		

### Packaging Instructions and Decal Placement

#### D350-600-142

Secure the box by applying clear tape over it. Place MFSP Kit and then insert spacepod. Wrap spacepod floor in foam and place next to spacepod, then insert hardware kit and paperwork. Close box, strap three times, and apply clear tape over strappings. Apply D2729-3 label as per instructions in QSI 014.

D2729-4

D2729-3

DART		PART NUMBER	
PART	N/A	QTY	CHG005
P/N	D350-600-142	QTY	SH93-88
DESC	Spacepod, RH	QTY	SR00098NY
LOT	BXXXXXX	QTY	SR00099NY
DATE	AS350/355		
TO APPROVAL # 0000		MADE IN CANADA	

DART AEROSPACE		<b>Dart Aerospace Ltd.</b> 1270 Aberdeen Street Hawkesbury, ON K6A 1K7 CANADA TEL.: 1 613 632-5200
SPACEPOD, UPWARD OPENING, RH		
P/N: D350-600-142		CHG005
B/N: BXXXXXX		

Revision: F  
Date: 14.07.28